

Ah-Hoc, PAN, Sensors, ...

- Introduction
- Bluetooth
- Zigbee

Renato Lo Cigno
www.dit.unitn.it/locigno/didattica/wn/

...Copyright

Quest'opera è protetta dalla licenza *Creative Commons NoDerivs-NonCommercial*. Per vedere una copia di questa licenza, consultare: <http://creativecommons.org/licenses/nd-nc/1.0/> oppure inviare una lettera a: *Creative Commons, 559 Nathan Abbott Way, Stanford, California 94305, USA.*

This work is licensed under the *Creative Commons NoDerivs-NonCommercial* License. To view a copy of this license, visit: <http://creativecommons.org/licenses/nd-nc/1.0/> or send a letter to *Creative Commons, 559 Nathan Abbott Way, Stanford, California 94305, USA.*

- Thanks: Prof. Mario Gerla, UCLA, for providing most of the material



Reti Ad Hoc

- Sono reti che vengono costituite dagli utenti stessi della rete, ad esempio tramite le funzioni BSS delle reti 802.11
- Supportano (in genere) una comunità chiusa nello spazio e nel tempo
- Hanno caratteristiche molto specifiche, legate alla necessità di costruire topologicamente la rete nel momento in cui serve



Reti di Sensori

- Sono reti ad Hoc studiate specificatamente per il supporto di strumenti di misura
- Oltre ai comuni problemi delle reti ad hoc devono anche ottimizzare l'aspetto energetico, perche` in genere sono alimentate a batteria
- Applicazioni (ed esigenze) piu` disparate dal monitoraggio ambientale all'allarme domestico senza fili




Reti "personali"

- PAN "personal area network"
- Reti a cortissimo raggio (1-5m) e bassissima potenza
- Dedicata a collegare tra loro i dispositivi "personali"
 - auricolare con cellulare
 - PDA, cellulare, orologio, sveglia ...
 - mouse e laptop
 - ...





Bluetooth Specifications





- A hardware/software/protocol description
- An application framework

















Bluetooth Physical link


• Point to point link

- master - slave relationship
- radios can function as masters or slaves



• Piconet

- Master can connect to 7 slaves
- Each piconet has max capacity = 1 Mbps
- hopping pattern is determined by the master




Renato.LoCigno@dit.unitn.it

AdHoc - PAN - Sensors 13

Connection Setup

• Inquiry - scan protocol


- to learn about the clock offset and device address of other nodes in proximity



Renato.LoCigno@dit.unitn.it

AdHoc - PAN - Sensors 14

Inquiry on time axis




Renato.LoCigno@dit.unitn.it


AdHoc - PAN - Sensors 15

Piconet formation

- Page - scan protocol
 - to establish links with nodes in proximity




- Master
- Active Slave
- Parked Slave
- Standby



Renato.LoCigno@dit.univr.it
AdHoc - PAN - Sensors 16


Addressing


- Bluetooth device address (BD_ADDR)
 - 48 bit IEEE MAC address
- Active Member address (AM_ADDR)
 - 3 bits active slave address
 - all zero broadcast address
- Parked Member address (PM_ADDR)
 - 8 bit parked slave address



Renato.LoCigno@dit.univr.it
AdHoc - PAN - Sensors 17


Piconet channel




Renato.LoCigno@dit.univr.it
AdHoc - PAN - Sensors 18







Packet Format

72 bits

54 bits

Header

0 - 2744 bits

Payload

Voice

No CRC
No retries
FEC (optional)

Data CRC

ARQ
FEC (optional)

Renato.LoCigno@dit.unitn.it
AdHoc - PAN - Sensors 22

Access Code

72 bits

Purpose

- Synchronization
- DC offset compensation
- Identification
- Signaling

Types

- Channel Access Code (CAC)
- Device Access Code (DAC)
- Inquiry Access Code (IAC)

Renato.LoCigno@dit.unitn.it
AdHoc - PAN - Sensors 23

Packet Header

54 bits


Purpose


- Addressing (3) → Max 7 active slaves
- Packet type (4) → 16 packet types (some unused)
- Flow control (1) → Broadcast packets are not ACKed
- 1-bit ARQ (1) → For filtering retransmitted packets
- Sequencing (1) → Verify header integrity
- HEC (8)


total	18 bits
-------	---------


Encode with 1/3 FEC to get 54 bits


Renato.LoCigno@dit.unitn.it
AdHoc - PAN - Sensors 24














Scatternet

Renato.LoCigno@dit.unitn.it AdHoc – PAN – Sensors 31

Scatternet, scenario 2


How to schedule presence in two piconets?
Forwarding delay ?
Missed traffic?


Renato.LoCigno@dit.unitn.it AdHoc – PAN – Sensors 32


Baseband: Summary

- TDD, frequency hopping physical layer
- Device inquiry and paging
- Two types of links SCO and ACL links
- Multiple packet types (multiple data rates with and without FEC)

Renato.LoCigno@dit.unitn.it AdHoc – PAN – Sensors 33







Low power mode (Sniff)

Slave

Sniff offset

Sniff duration

Sniff period

Master

- Traffic reduced to periodic sniff slots

Renato.LoCigno@dit.univr.it AdHoc - PAN - Sensors 37

Low power mode (Park)

Slave

Beacon instant

Master

Beacon interval

- Power saving + keep more than 7 slaves in a piconet
- Give up active member address, yet maintain synchronization
- Communication via broadcast LMP messages

Renato.LoCigno@dit.univr.it AdHoc - PAN - Sensors 38

Connection establishment & Security

- Goals
 - Authenticated access
 - Only accept connections from trusted devices
 - Privacy of communication
 - prevent eavesdropping
- Constraints
 - ▶ Processing and memory limitations
 - \$10 headsets, joysticks
 - ▶ Cannot rely on PKI
 - ▶ Simple user experience

Master

Slave

Paging

LMP_host_conn_req

LMP Accepted

Security procedure


LMP_setup_complete

LMP_setup_complete

Renato.LoCigno@dit.univr.it AdHoc - PAN - Sensors 39


Authentication

- Authentication is based on link key (128 bit shared secret between two devices)
- How can link keys be distributed securely ?




Pairing (key distribution)

- Pairing is a process of establishing a trusted secret channel between two devices (construction of initialization key K_{init})
- K_{init} is then used to distribute unit keys or combination keys





Link Manager Protocol Summary




- Piconet management
- Link configuration
 - Low power modes
 - QoS
 - Packet type selection
- Security: authentication and encryption









Segmentation and reassembly

- cannot cope with re-ordering or loss
- mixing of multiple L2CAP fragments not allowed
- If the start of L2CAP packet is not acked, the rest should be discarded

min MTU = 48
672 default

Renato.LoCigno@dit.unitn.it AdHoc – PAN – Sensors 46

Bluetooth Service Discovery Protocol


Renato.LoCigno@dit.unitn.it AdHoc – PAN – Sensors 47

Example usage of SDP

- Establish L2CAP connection to remote device
- Query for services
 - search for specific class of service, or
 - browse for services
- Retrieve attributes that detail how to connect to the service
- Establish a separate (non-SDP) connection to use the service

Renato.LoCigno@dit.unitn.it AdHoc – PAN – Sensors 48

Serial Port Emulation using RFCOMM



Serial Port emulation on top of a packet oriented link

- Similar to HDLC
- For supporting legacy apps



Serial line emulation over packet based MAC




• Design considerations

- framing: assemble bit stream into bytes and, subsequently, into packets
- transport: in-sequence, reliable delivery of serial stream
- control signals: RTS, CTS, DTR



IP over Bluetooth V 1.0



GOALS


- Internet access using cell phones
- Connect PDA devices & laptop computers to the Internet via LAN access points



Bluetooth Current Market Outlook



Market Forecasts for year 2005



Biggest challenges facing Bluetooth

- Interoperability
 - Always a challenge for any new technology
- Hyped up expectations
- Out of the box ease of use
- Cost target \$5
- Critical mass
- RF in silicon
- Conflicting interests - business and engineering



Value to carriers: Synchronization and Push



- More bits over the air
- Utilization of unused capacity during non-busy periods
- Higher barrier for switching service providers



Value to carriers: Cell phone as an IP gateway



Will Pilot and cell phone eventually merge?

- More bits over the air
- Enhanced user experience
 - Palmpilot has a better UI than a cell phone
- Growth into other vertical markets



Value to carriers: Call handoff

Threat or opportunity?




- More attractive calling plans
- Alleviate system load during peak periods
- Serve more users with fewer resources



ZigBee and 802.15.4 for Personal Area and Sensor Networks


Outline

- ZigBee and 802.15.4 solution
- ZigBee vs Bluetooth
- Applications
- Conclusions


 Renato.LoCigno@dit.univr.it AdHoc – PAN – Sensors 59

The ZigBee Alliance Solution


- Targeted at home and building automation and controls, consumer electronics, PC peripherals, medical monitoring, and toys
- Industry standard through application profiles running over IEEE 802.15.4 radios
- Primary drivers are **simplicity, long battery life, networking capabilities, reliability, and cost**
- Alliance provides interoperability and certification testing

 Renato.LoCigno@dit.univr.it AdHoc – PAN – Sensors 60

The Wireless Market



Applications




Promoter Companies



Development of the Standard

- **ZigBee Alliance**
 - 50+ companies: semiconductor mfrs, IP providers, OEMs, etc.
 - Defining upper layers of protocol stack: from network to application, including application profiles
 - First profiles published mid 2003
- **IEEE 802.15.4 Working Group**
 - Defining lower layers of protocol stack: MAC and PHY released May 2003



Renato.LoCigno@dit.unitn.it

AdHoc - PAN - Sensors 64

IEEE 802.15.4 Basics

- 802.15.4 is a simple packet data protocol for lightweight wireless networks
 - Channel Access is via Carrier Sense Multiple Access with collision avoidance and optional time slotting
 - Message acknowledgement and an optional beacon structure
 - Multi-level security
 - Three bands, 27 channels specified
 - 2.4 GHz: 16 channels, 250 kbps
 - 868.3 MHz : 1 channel, 20 kbps
 - 902-928 MHz: 10 channels, 40 kbps
 - Works well for
 - Long battery life, selectable latency for controllers, sensors, remote monitoring and portable electronics
 - Configured for maximum battery life, has the potential to last as long as the shelf life of most batteries



Renato.LoCigno@dit.unitn.it

AdHoc - PAN - Sensors 65


IEEE 802.15.4 Device Types

- Three device types
 - Network Coordinator
 - Maintains overall network knowledge; most sophisticated of the three types; most memory and computing power
 - Full Function Device
 - Carries full 802.15.4 functionality and all features
 - Additional memory, computing power make it ideal for a network router function
 - Could also be used in network edge devices (where the network touches the real world)
 - Reduced Function Device
 - Carriers limited (as specified by the standard) functionality to control cost and complexity
 - General usage will be in network edge devices
- All of these devices can be no more complicated than the transceiver, a simple 8-bit MCU and a pair of AAA batteries!



Renato.LoCigno@dit.unitn.it

AdHoc - PAN - Sensors 66




- ### MAC Options
- Two channel access mechanisms
 - Non-beacon network
 - Standard CSMA-CA communications
 - Positive acknowledgement for successfully received packets
 - Beacon-enabled network
 - Superframe structure
 - For dedicated bandwidth and low latency
 - Set up by network coordinator to transmit beacons at predetermined intervals
 - » 15ms to 252sec
($15.38ms \cdot 2^n$ where $0 \leq n \leq 14$)
 - » 16 equal-width time slots between beacons
 - » Channel access in each time slot is contention free
- Renato.LoCigno@dit.univr.it AdHoc – PAN – Sensors 68

- ### Non-Beacon vs Beacon Modes
- Non-Beacon Mode
 - A simple, traditional multiple access system used in simple peer and near-peer networks
 - Think of it like a two-way radio network, where each client is autonomous and can initiate a conversation at will, but could interfere with others unintentionally
 - However, the recipient may not hear the call or the channel might already be in use
 - Beacon Mode
 - A very powerful mechanism for controlling power consumption in extended networks like cluster tree or mesh
 - Allows all clients in a local piece of the network the ability to know when to communicate with each other
 - Here, the two-way radio network has a central dispatcher who manages the channel and arranges the calls
 - As you'll see, the primary value will be in system power consumption
- Renato.LoCigno@dit.univr.it AdHoc – PAN – Sensors 69

Example of Non-Beacon Network

- Commercial or home security
 - Client units (intrusion sensors, motion detectors, glass break detectors, standing water sensors, loud sound detectors, etc)
 - Sleep 99.999% of the time
 - Wake up on a regular yet random basis to announce their continued presence in the network ("12 o'clock and all's well")
 - When an event occurs, the sensor wakes up instantly and transmits the alert ("Somebody's on the front porch")
 - The ZigBee Coordinator, mains powered, has its receiver on all the time and so can wait to hear from each of these station.



Renato.LoCigno@dit.unitn.it

AdHoc - PAN - Sensors 70

Example of Beacon Network


- Now make the ZigBee Coordinator battery-operated also
 - All units in system are now battery-operated
 - Client registration to the network
 - Client unit when first powered up listens for the ZigBee Coordinator's network beacon (interval between 0.015 and 252 seconds)
 - Register with the coordinator and look for any messages directed to it
 - Return to sleep, awaking on a schedule specified by the ZigBee Coordinator
 - Once client communications are completed, ZigBee coordinator also returns to sleep



Renato.LoCigno@dit.unitn.it

AdHoc - PAN - Sensors 71

ZigBee and Bluetooth



Competitive or Complementary?

ZigBee and Bluetooth


Optimized for different applications

- **ZigBee**
 - Smaller packets over large network
 - Mostly Static networks with many, infrequently used devices
 - Home automation, toys, remote controls, etc.
- **Bluetooth**
 - Larger packets over small network
 - Ad-hoc networks
 - File transfer
 - Screen graphics, pictures, hands-free audio, Mobile phones, headsets, PDAs, etc.



ZigBee and Bluetooth

Address Different Needs



- Bluetooth is a cable replacement for items like Phones, Laptop Computers, Headsets
- Bluetooth expects regular charging
 - Target is to use <10% of host power




ZigBee and Bluetooth

Address Different Needs

- ZigBee is better for devices where the battery is 'rarely' replaced
 - Targets are :
 - Tiny fraction of host power
 - New opportunities where wireless not yet used







An Application Example

Battery Life & Latency in a Light Switch


- **Wireless Light switch**
 - Easy for Builders to Install
- **A Bluetooth Implementation would:**
 - use the inquiry procedure to find the light each time the switch was operated.

Renato.LoCigno@dit.unitn.it AdHoc – PAN – Sensors 77

Light switch using Bluetooth

- **Inquiry procedure to locate light each time switch is operated**
 - Bluetooth 1.1 = up to 10 seconds typical
 - Bluetooth 1.2 = several seconds even if optimized
- **Unacceptable latency**



Renato.LoCigno@dit.unitn.it AdHoc – PAN – Sensors 78

Light switch using ZigBee


- With DSSS interface, only need to perform CSMA before transmitting
 - Only 200 μ s of latency
 - Highly efficient use of battery power

ZigBee offers longer battery life and lower latency than a Bluetooth equivalent



ZigBee and Bluetooth: Conclusion

- ZigBee targets applications not addressable by Bluetooth or any other wireless standard
- ZigBee and Bluetooth complement for a broader solution



Reliability and Robustness throughout the stacks of IEEE 802.15.4 and ZigBee


Reliability

Network:

- **Mesh Networking:** allows various paths of routing data to the destination device. In this way if a device in the primary route is not able to pass the data, a different valid route is formed, transparent to the user.



Reliability: Mesh Networking



Wireless Keyboard

- Battery-operated keyboard
 - Part of a device group including a mouse or trackball, sketchpad, other human input devices
 - Each device has a unique ID
 - Device set includes a USB to wireless interface dongle
 - Dongle powered continuously from computer
 - Keyboard does not have ON/OFF switch
 - Power modes
 - Keyboard normally in lowest power mode
 - Upon first keystroke, wakes up and stays in a "more aware" state until 5 seconds of inactivity have passed, then transitions back to lowest power mode



Keyboard Usage

- **Typing Rates**
 - 10, 25, 50, 75 and 100 words per minute
- **Typing Pattern**
 - Theoretical: Type continuously until battery is depleted
 - Measures total number of hours based upon available battery energy



Wireless Keyboard Using 802.15.4

- **802.15.4 Operation Parameters**
 - Star network
 - Non-beacon mode (CSMA-CA)
 - USB Dongle is a PAN Coordinator Full Functional Device (FFD)
 - Keyboard is a Reduced Function Device (RFD)
 - **Power Modes**
 - Quiescent Mode used for lowest power state
 - » First keystroke latency is approx 25ms
 - Idle mode used for "more aware" state
 - » Keystroke latency 8-12 ms latency



Wireless Keyboard Using 802.15.4

- **802.15.4 Chipset Parameters**
 - Motorola 802.15.4 Transceiver and HCS08 MCU
 - Battery operating voltage 2.0 - 3.6 V
 - All required regulation internal to ICs
 - Nearly all available energy usable with end of life voltage at 2.0 volts




Wireless Keyboard Using Bluetooth

- Bluetooth Operation Parameters
 - Piconet network
 - USB Dongle is piconet Master
 - Keyboard is a piconet Slave
 - Power Modes
 - Park mode used for lowest power state
 - » 1.28 second park interval
 - » First keystroke latency is 1.28s
 - Sniff mode used for "more aware" state
 - » 15ms sniff interval
 - » 15ms latency



BT vs. 15.4 Keyboard Comparison



Conclusion

- Bluetooth and 802.15.4 transceiver physical characteristics are very similar
- Protocols are substantially different and designed for different purposes
- 802.15.4 designed for low to very low duty cycle static and dynamic environments with many active nodes
- Bluetooth designed for high QoS, variety of duty cycles, moderate data rates in fairly static simple networks with limited active nodes
- Bluetooth costs and system performance are in line with 3rd and 4th generation products hitting market while 1st generation 15.4 products will be appearing only late this year